



REPLACEMENT SHEET

3 / 7

FIG. 3

FIG. 3 is a screenshot of a software interface for a replacement sheet, showing various settings and options.

The interface is divided into several sections:

- PAPER SIZE (APPLICATION):** A dropdown menu showing "A4 210×297mm" (labeled 301).
- PRINT DIRECTION:** Radio buttons for "PORTRAIT" (selected) and "LANDSCAPE".
- PRINT TYPE:** Radio buttons for "NON-SCALING" (selected), "SCALING", "N-UP", "BROCHURE", "POSTER", and "BANNER". These options are grouped by a bracket labeled 304.
- OUTPUT PAPER SIZE (PRINTER):** A dropdown menu showing "A4 210×297mm" (labeled 302).
- Background and Copies:** A checkbox for "BACKGROUND" (checked, labeled 303) and a "COPIES" field set to "1" with a spinner button.
- Duplex and Binding:** A checkbox for "DUPLEX:" and radio buttons for "LATERAL BINDING" (selected) and "TOP/BOTTOM BINDING".
- Reverse Order and Copy by Copy:** Radio buttons for "REVERSE ORDER" and "COPY BY COPY".
- Buttons:** "CONTROL PRINTER" and "RESTORE" buttons are located below the main settings.
- Footer Buttons:** "OK", "CANCEL", "APPLY", and "HELP" buttons are at the bottom.